

N.B.

It is advisable to:

- a. protect carpets from brick/mortar dust by laying plastic sheeting or other protection before commencing drilling.
- b. have your drill lead connected to a safety trip box especially when drilling near any power point in the wall.
- c. wear safety glasses and ear muffs/plugs when drilling.
- d. be aware of water pipes when drilling near bathrooms or any wall which may have water pipes in them. It is advisable to turn off the water at the main tap if there is a risk of hitting a water pipe.
- e. clean up any brick/mortar dust before inserting the Dryrod
- f. wear gloves and wash hands with soap and water if in contact with a Dryrod

Replastering

When replastering internal walls it is essential that you or your plasterer follow these instructions to minimize the risk of any residual moisture and/or salts remaining in the walls affecting the new plaster.

1. It is recommended to leave the existing render on walls for at least six months to act as a sacrificial poultice to help draw out residual moisture remaining in the walls above the Dryrod Treatment and then remove render to a height of at least 100mm above all affected render.
2. Render with 3-4 parts renderers sand with 1 part cement (do not add lime). **Add a suitable moisture barrier to the mix**, we recommend Cementaid "Aquapel" and/or Aftek "Number 2 paste". These products are available from builders' hardware stores only and not general hardware stores.

Note

Please do not hesitate to call Peter on 0402 278 053 if you have any questions regarding these instructions or need any further advice.